English

Default settings shaded.

Default settings shaded. Main menu		Sub menu		Display	Function
SET ADDRESS		A001 ~ A508		DMX address setting	
USER MODE		Channel Mode: 05 / 06 / 07			DMX channel mode
FUNCTION	Status	No DMX status		Close/Hold	Modes if no DMX
	Fixture ID	Service PIN		Password=XXX	Passwort "050"
		RDM PID		XXXXXX	
	Dimmer Curve	Linear	The increase in light intensity appears to be DMX value is increased		
		Square Light intensity control is finer at lo high levels			
		INV. Square Light intensity control is coarser high levels			
		S-Curve Light intensity control is fine at low and coarser at medium levels			
	Lamp Behavior	LED			
	- P	Halogen		2514 2214	5
	LCD. Set	Backlight		05M ~ 60M	Display shutoff time
		Key lock		ON/OFF	Key lock activation
		DispFlash		ON/OFF	Setting that the device will flash when there is no DMX signal received
	Load	ON/OFF			Restore factory settings
	Temp. C/F	Celsius		Select temperature	
		Fahrenheit		designation °C or °F	
INFORMATION	Time. Info	Current		XXXX (h)	Power on running time
		Total time		XXXX (h)	Fixture running time
		Last clear		XXXX (h)	Individual fixture running time
		Timer PIN		Password="050"	
	Temp. Info	XXX °C/°F			Inside temperature
	Model. Info	LED THA-60PC		Model name	
	Software version	V 0.03		<u> </u>	Software version
TEST	Panel. Ctrl.	Dimmer = 000-255			Manual adjustment
	Panel. Ctrl.	Strobe = 000-2			Manual adjustment
	Program	Static F: 0		G/B/RG/GB/RB/RGB/E 00 - 99	BLAC Manual adjustment
		Change	F:	P: 01 – 99 00 – 99	Manual adjustment
		Fade	F:	P: 01 – 99 00 – 99 P: 01 – 99	Manual adjustment
		Auto F: 0		00 - 99	Manual adjustment
	Sound	Sense 00 - 31		Manual adjustment	